

# MUTHA HUBBA™ NX

## Assembly Instructions




### PACKAGE INCLUDES:

Frame assembly, tent body, rainfly, stakes


## 1 PREPARE FOR SETUP

1. Spread tent out and stake out four corners tightly.
2. Assemble poles.




## 2 ASSEMBLE TENT FRAME

1. Insert tips of long main poles into grommets at the stake loops.
2. Insert ridge pole into grommets above doors.
3. Attach clips to frame.



## 3 ATTACH CROSS POLE

1. Insert short cross pole into grommets at tent's midpoint.
2. Attach clips.



## 4 ATTACH RAINFLY

1. Lay rainfly over tent. Attach the rainfly's midpoint grommets to ridge pole. Secure rainfly Velcro tabs to main poles.
2. Place rainfly's adjustable loop grommets under the main pole ends at corners.
3. Stretch out vestibules until taut and stake down, making sure seams align with frame.



**USE TIPS:** All tents require staking; unsecured tents are susceptible to wind damage. In some conditions, additional stakes and cord may be required. Re-adjustment of stakes and rainfly may be necessary to keep tent tight and weatherproof. For complete care and use instructions, refer to the Owner's Manual (available at [www.msrgear.com/MuthaHubbaNX](http://www.msrgear.com/MuthaHubbaNX)).



MOUNTAIN SAFETY RESEARCH®

© 2016 Cascade Designs, Inc.

4000 First Avenue South

Seattle, WA 98134 USA

1-800-531-9531 | 1-206-505-9500